

EM01R Unit:mm



SPECIFICATIONS

Power supply	2xAAA 1.5V battery
Upload range	Up to 15m (50ft)
Op. temperature	0°C~50°C (32°F~122°F)
Dimensions	39x143x15mm (1.53"x5.62"x0.59")

Test button & LED indicator

Operations	Test button operations	Remote control operations	Indicator status	Working status
Normal mode	Press the test button	Press button A	OFF	Emergency mode
	/	Press button B	OFF	Monthly testing
	/	Press button C	OFF	Annual testing
	/	/	ON	Battery is charging or fully charged
	Press the test button 5 times within 5S	Press button D 10S	Flashing 3 times	Bluetooth reset
Emergency mode	Press the test button 5S	/	OFF	Turn off the battery pack
Malfunction mode	/	/	Flashing	1.The battery pack is disconnected or it is broken. 2.The load is disconnected. 3.Short circuit or open circuit. 4.The wires are not connected properly.

*Note:After power on the Bluetooth EM,LED red indicator light breathing means the EM device have been connected by another user and weren't correctly disconnected,please use the remote control to reset it or press the test butoon 5 times within 5S to reset the EM.